

# VENALINK QUBE 2PSA

## HOW TO PRODUCE THE PERFECT SEAL



### 1. CREASE

- Take the card out of the box
- Turn over the card to view the inside
- Fold the right panel over covering the centre panel of the card
- Crease the folded edge with your fingers



### 2. PEEL

- Open out the card
- Place the right panel over the foam template
- Peel back the white paper to reveal the right panel
- Line up the card holes with the foam template



### 3. ALIGN

- Line up the blister with the card holes and place inside the card
- Smooth over the top of the blister with your hand
- Peel off the remaining white paper from the centre panel



### 4. FOLD & TURN

- Fold the left and centre panel over
- Rub over the back with your hand to pre-seal
- Turn the card 45° anticlockwise, from portrait to landscape



### 5. SEAL

- Using the roller, roll from bottom to top applying pressure
- Repeat this to cover the entire surface
- Ensure you roll right over the edges of the card



### 6. ROLL

- Turn the card 45° clockwise, taking the card from landscape to portrait
- Using the roller, roll from bottom to top applying pressure
- Repeat this to cover the entire surface
- Ensure you roll right over the edges of the card



### 7. VENALINK CARD & BLISTER

- Take the card out of the foam template
- Fold the cover over

How To Video: [www.tinyurl.com/venalinkqube](http://www.tinyurl.com/venalinkqube)



Connect with us @Venalink  
sales@venalink.co.uk  
[www.venalink.co.uk](http://www.venalink.co.uk)