

# VENALINK QUBE

## HOW TO PRODUCE THE PERFECT SEAL



### 1. CREASE

- Take the card out of the box
- Turn over the card to view the inside
- Fold the right panel over covering the centre panel of the card
- Crease the folded edge with your fingers



### 2. ALIGN & PEEL

- Open out the card
- Place the right panel over the foam template
- Line up the card holes with the foam template
- Line up the blister with the card holes and place inside the card
- Smooth over the top of the blister with your hand
- Peel off the white paper to reveal the middle panel
- It is important that you peel the backing paper off from left to right



### 3. FOLD & TURN

- Fold the left and centre panel over
- Rub over the back with your hand to pre-seal
- Turn the card 45° anticlockwise, from portrait to landscape



### 4. SEAL

- Using the roller, roll from bottom to top applying pressure
- Repeat this to cover the entire surface
- Ensure you roll right over the edges of the card



### 5. ROLL

- Turn the card 45° clockwise, taking the card from landscape to portrait
- Using the roller, roll from bottom to top applying pressure
- Repeat this to cover the entire surface
- Ensure you roll right over the edges of the card



### 6. VENALINK CARD & BLISTER

- Take the card out of the foam template
- Fold the cover over