01244 287050

f: 01244 289175

e: sales@venalink.co.uk

www.venalink.co.uk

Unit 46, First Av, Zone 2, Deeside Ind. Park CH5 2NU

## HOW TO PRODUCE THE PERFECT SEAL - AM/PM





## 1. ALIGN

- Place your AM/PM card on your sealing template
- Place in the AM/PM blister





## 2. PEEL & FOLD

- Remove the backing paper and fold over the foil panel.
- Smooth over the card with your hand.





## 3. ROLL

- Using your roller, roll the card ensuring enough pressure is applied.
- Fold up the card to complete assembly