01244 287050

f: 01244 289175

e: sales@venalink.co.uk www.venalink.co.uk

Unit 46, First Av, Zone 2, Deeside Ind. Park CH5 2NU

HOW TO PRODUCE THE PERFECT SEAL - QUBE CLEAR





1. **ALIGN & PEEL1**

- Open your Qube Clear tray
- Locate "Peel 1" on your seal and peel away to expose the adhesive strip
- Using the two locator corners on the tray line up and attach the seal
- Smooth over the top of the adhesive





PEEL 2 2.

- Remove "Peel 2" on the seal to expose the remaining adhesive
- Smooth down the seal over the tray
- Use your roller to roll the card.
- Ensure rolling has made the pull tabs prominent from the seal





3. **INSERT**

Add the paper insert into the lid to finish assembling